

BLACK PVC BACKING STRIP INSTALLATION ADHESION TO FRAMEWORK METHOD

Wall or Ceiling Application

BLACK PVC BACKING STRIP
MOUNTED TO FURRING CHANNEL

FURRING
CHANNEL
FRAMING

DECORZEN
PERFORATED
FACE FIX PANEL

Disclaimer:

All specifications shown in these documents are intended as a guide only & should not be considered as conclusive. Fixing types & sizes used to install these products must be considered in conjunction with site conditions.

It is the users responsibility to ensure the use of this document coincides with their own judgement and is appropriate for the application.
Decor Systems cannot be held responsible for any consequences arising from the improper use of this material (whether negligence or otherwise.)

Thoroughly clean the adhesion area with isopropyl alcohol or acetone, ensuring it's free of dust and debris before applying the strip.

THESE DESIGNS, DRAWINGS & SPECIFICATIONS
& COPYRIGHT THEREOF ARE THE PROPERTY OF
DECOR SYSTEMS AUSTRALIA & MUST NOT BE USED,
RETAINED OR COPIED WITHOUT THE WRITTEN
AUTHORITY OF DECOR SYSTEMS AUSTRALIA.

 **DECOR
SYSTEMS**