





DecorArti with DSB Fixing Method

Wall or Ceiling Application




NOTE: FIXED FROM FRONT
(face fixed)
Use black screws (supplied, secret fix)
NOT suitable for Ø5mm or less

Fixings: Recommend 4G x 32mm CSK, black tipped (supplied)



Detail A - 1:5



Detail B - 1:10

Disclaimer:

All specifications shown in these documents are intended as a guide only & should not be considered as conclusive. Fixing types & sizes used to install these products must be considered in conjunction with site conditions.

It is the users responsibility to ensure the use of this document coincides with their own judgment and is appropriate for the application. Decor Systems cannot be held responsible for any consequences arising from the improper use of this manual (whether negligence or otherwise).

Installation Guide

1. Set out the timber studs or steel sections to suit the size of the panels. Recommendation of 400mm centres.
2. Locate & position timber panels, fixing through the perforation of the panel, through the DSB & into your framework [Detail A & B].
3. Continue with the remainder of the panels until whole wall or ceiling area is clad.