




# DecorSlat with Face Access Fixing Method


## Wall or Ceiling Application




Fixings: Recommend 6G x 32mm CSK, black tipped (NOT supplied).  
Length dependant on the structure being mounted on.



NOTE: FIXED FROM FRONT  
(face fixed)  
Use black screws (not supplied, secret fix)



Detail A - 1:5



Detail B - 1:10

### Disclaimer:

All specifications shown in these documents are intended as a guide only & should not be considered as conclusive. Fixing types & sizes used to install these products must be considered in conjunction with site conditions.

It is the users responsibility to ensure the use of this document coincides with their own judgment and is appropriate for the application. Decor Systems cannot be held responsible for any consequences arising from the improper use of this manual (whether negligence or otherwise).

## Installation Guide

1. Set out timber studs or steel sections to suit the size of the panels. Recommendation of 400mm centres. Clad with plasterboard.
2. Locate & position timber panels, fixing through the face of the panel (on an angle if required) into your framework [Detail A & B].
3. Continue with the remainder of the panels until whole wall or ceiling area is clad.

THESE DESIGNS, DRAWINGS & SPECIFICATIONS & COPYRIGHT THEREOF ARE THE PROPERTY OF DECOR SYSTEMS AUSTRALIA & MUST NOT BE USED, RETAINED OR COPIED WITHOUT THE WRITTEN AUTHORITY OF DECOR SYSTEMS AUSTRALIA.