




These SKB locks are preset at the factory to unlock at **0 - 0 - 0**.

Make sure you are able to open and close the lock prior to setting your own combination.



1. To open the lock, turn the dials to the correct combination (make sure the numbers are lined up to the notching line) and push the button under the cable to open. If you are setting the combination for the first time, the default combination is **0 - 0 - 0**.

2. Use a pen or pin tool to push the combination resetter and slide it across the slot. Once the resetter is in place, you are ready to reset the combination.

3. Set your combination by turning the dials to your desired number sequence, making sure the numbers are aligned with the notching line.

4. Slide the reset button back to its original position. Your new combination is now set. **NOTE: You will not be able to reset the combination again without knowing your current combination, so please make note of it for future reference.** To reset the combination, repeat steps 1-4.



Visit us online at www.skbcases.com