

How does one use a candle water filter?

1



Pour the water into the top chamber and close the lid.

2



Filtered water will start flowing immediately to the bottom chamber. The water will flow faster when the top chamber is full, so fill it often.

3



The water can then be collected from the tap.

Note: Please throw away the filtered water in the garden the first 3 times to avoid the bad smell.

How does one assemble a candle water filter?

1



Wash your hands with soap.

2



Fix the candle at the bottom of the top chamber. Tighten the screws. Make sure it is fixed properly and doesn't move.

3



Fix the tap in the bottom chamber. Tighten the screws. Make sure it is fixed properly and doesn't move.

4



Fix the knob on top of the lid. Tighten the screws. Make sure it is fixed properly and doesn't move.

5



Place the filter at a height, so that it is easy to draw water from it.

Now, the filter is ready to be used!

How does one change the candle in the filter?

1



You can buy the candle from the shops in the market that sell water filters. It usually costs between Rs. 80 to Rs. 300.

2



Loosen the screws and remove the old candle.

3




Fix the new candle and tighten the screws. Make sure it is fixed properly and doesn't move.



When you can see a visible crack in the candle or when the flow is slow even after cleaning, it is time to change the candle. A candle usually lasts for about 6 months to 1 year.

filter treat water?



How does one clean the candle in the filter?



When the flow of water has become slower than normal, it is time to clean the candle. It may be useful to set up a specific date of the month to check and clean the filter, say the first day of the month.

How does a candle

